

# MACHINE SOLUTIONS INC.



## USER MANUAL

### BEAHM DESIGNS VERTICAL LAMINATOR MODEL 810-A



**BEAHM**  
DESIGNS

Machine Solutions Inc. 2951 W. Shamrell Blvd. Flagstaff, Arizona 86005 USA  
Tel: 928-556-3109 • Fax: 928-556-3084  
[Service@machinesolutions.com](mailto:Service@machinesolutions.com) • [www.machinesolutions.com](http://www.machinesolutions.com)



## Equipment User Manual

---

### Table of Contents

List of Figures .....	4
List of Tables .....	5
WELCOME.....	6
MACHINE DESCRIPTION .....	6
<i>Process Overview</i> .....	6
<i>Control System Overview</i> .....	7
SAFETY .....	7
INSTALLATION .....	8
Power Requirements .....	8
Facilities Requirements.....	8
<i>Main Power Disconnect Switch</i> .....	8
<i>Emergency Stop Loop and Hardwired Devices</i> .....	8
<i>Overtemperature Controllers</i> .....	9
Temperature Controller Uses Ethernet/IP Comms.....	9
Servo Drive(s) .....	9
Remote-In Communication Device .....	9
Optional Light Tower .....	9
<i>Barcode Scanning</i> .....	9
Barcode Scanner Connects to PanelView's USB Port .....	9
<i>Multi-Loop Controller Setup</i> .....	9
Four Control Loops.....	9
Auto Tuning Initiated by Digital Input 1.....	9
Thermocouple Offset .....	9
SERVO DRIVES.....	10
SET UP AND CONFIGURATION .....	10
CONTROLS.....	11
CALIBRATION .....	12
Tuning Temperature Controllers .....	12
PARAMETER SETTINGS.....	13
Laminator Settings Variables .....	13



## Equipment User Manual

---

PANEL VIEW PLUS HMI DISPLAY DESCRIPTION .....	15
Data Entry Keypads .....	15
Main Menu (Screen #01) .....	16
PLC STATUS AND HMI SHUTDOWN (SCREEN #02) .....	18
SETTINGS (SCREEN #03) .....	19
AUTO TUNE (SCREEN #04) .....	21
HEATER ACTUATOR (SCREEN #12) .....	22
HEATERS AND HEATER AIRFLOW (SCREEN #13) .....	24
PNEUMATICS AND VALVES (SCREEN #14) .....	26
CALIBRATION (SCREEN #15) (IF APPLICABLE) .....	27
RUN PARTS (SCREEN #10) .....	28
CYCLE START Pushbutton .....	30
CYCLE STOP Pushbutton .....	30
Run Parts Screen without Passcode .....	31
Passcode Cleared on Laminator Power Up .....	31
RECIPE SETTINGS AND DESCRIPTIONS .....	32
Alternate Units .....	32
RECIPE SELECT (SCREEN #20) .....	33
RECIPE EDIT (SCREEN #21) .....	34
HMI SUPPORT SCREENS .....	35
Alarm Banner Overlay .....	35
Alarm Log .....	36
ALARMS .....	38
Alarms while Processing .....	38
Airflow and Temperature Alarms .....	38
WARNINGS .....	39
LAMINATOR SETTINGS AND RECIPE CONTROLS .....	40
Alternate Display Unit .....	40
Passcode Required to Change Settings .....	40
Laminator Settings Variables .....	40
SYSTEM OPERATION .....	43



## Equipment User Manual

---

TERMS AND DEFINITIONS .....	44
MAINTENANCE.....	45
Cleaning.....	45
Replacing Thermal Nozzles .....	46
Exchanging Vee Guide/insert(s) .....	47
Replace Heating Element(s) .....	48
Replace Heater Power Controller .....	49
Aligning Tooling.....	51
SYSTEM SPECIFICATIONS .....	52
CRITICAL PARTS LIST .....	53
DIAGNOSTICS (TROUBLESHOOTING).....	54
Ethernet Connections and IP Addresses .....	54
APPENDIX.....	55
Sequences of Operation.....	55
Master Control Sequence .....	55
SERVO MOTOR CONTROL SEQUENCE .....	59
AIRFLOW AND TEMPERATURE CONTROLS .....	60
Air Flow Controls.....	60
Heater Overtemperature Control.....	60
Multi-Loop Temperature Controller .....	60
Auto Tuning Triggered by the PLC .....	60
Heater / Airflow Multistate Indicator .....	60
Thermocouple Offset .....	61
CUSTOMER SUPPORT AND SATISFACTION .....	62
WARRANTY AND LIMITATIONS.....	63

## List of Figures

Figure 1. HMI Keypad .....	15
Figure 2. Main Menu .....	16
Figure 3. Operator screen .....	17
Figure 4. Shutdown Screen .....	18
Figure 5. Settings Screen .....	19
Figure 6. Limit Settings .....	20
Figure 7. Auto Tune Screen .....	21
Figure 8. Heater Actuator Screen.....	22
Figure 9. Heaters and Heater Airflow Screen .....	24
Figure 10. Pneumatics and Valve Screen .....	26
Figure 11. Airflow Calibration Screen .....	27
Figure 12. Run Screen.....	28
Figure 13. Run Parts Screen .....	31
Figure 14. Recipe Select Screen .....	33
Figure 15. Recipe Edit Screen .....	34
Figure 16. Shutdown Screen .....	35
Figure 17. Alarm Banner .....	36
Figure 18. Alarm Log.....	37
Figure 19: Replacing Thermal Nozzles – Remove Heat Shield .....	46
Figure 20: Replacing Thermal Nozzles – Nozzle Set Screw .....	47
Figure 21: Exchanging Vee Guide/Inserts.....	47
Figure 22: Replace Heating Elements - Top Cover Removal .....	48
Figure 23: Replace Heating Elements – Remove/install Heater .....	49
Figure 24: Replace Heater Power Controller - Locate Controller .....	50
Figure 25: Replace Heater Power Controller .....	50
Figure 26: Aligning Tooling.....	51

## List of Tables

<b>Table 1. Set up and Configuration.</b>	<b>10</b>
<b>Table 2. Controls.</b>	<b>11</b>
<b>Table 3. Parameter Settings</b>	<b>13</b>
<b>Table 4. HMI Display Descriptions</b>	<b>16</b>
<b>Table 5. Shutdown Screen Button Description</b>	<b>18</b>
<b>Table 6. Settings Screen Button Description</b>	<b>19</b>
<b>Table 7. Limit Screen Button Description</b>	<b>20</b>
<b>Table 8. Auto Tune Button Description</b>	<b>21</b>
<b>Table 9. HMI Screen Objects - Actuator</b>	<b>22</b>
<b>Table 10. Heater Actuator Button Description.</b>	<b>23</b>
<b>Table 11. Heater Screen Button Description</b>	<b>25</b>
<b>Table 12. Pneumatics Screen Button Description</b>	<b>26</b>
<b>Table 13. Calibration Screen Objects</b>	<b>27</b>
<b>Table 14. HMI Screen Objects</b>	<b>28</b>
<b>Table 15. HMI Screen Objects - Run Screen</b>	<b>30</b>
<b>Table 16. Alternate Recipe Units</b>	<b>32</b>
<b>Table 17. Recipe Screen Button Description</b>	<b>33</b>
<b>Table 18. Recipe Edit Screen Button Description</b>	<b>34</b>
<b>Table 19. Alarm Message Description</b>	<b>38</b>
<b>Table 20. Warning Message Description</b>	<b>39</b>
<b>Table 21. Laminator Settings Variables</b>	<b>41</b>
<b>Table 22. Terms, Definitions and Descriptions.</b>	<b>44</b>
<b>Table 23. System Specifications</b>	<b>52</b>
<b>Table 24. Critical Spare Parts (contact Machine Solutions for current Price and delivery)</b>	<b>53</b>
<b>Table 25. Diagnostics</b>	<b>54</b>
<b>Table 26. Ethernet Connections and IP Addresses</b>	<b>54</b>
<b>Table 27. Master Control Sequence.</b>	<b>55</b>
<b>Table 28. Servo Motor Control Sequence and Description.</b>	<b>59</b>
<b>Table 29. Heater Multistate Indicator and Description</b>	<b>61</b>



## Equipment User Manual

---

---

### WELCOME

---

Machine Solutions, Inc. (MSI) would like to take this opportunity to thank you for purchasing your new 810-A Vertical Laminator machine. At MSI, we are dedicated to bringing innovative process development solutions to both medical device and nonmedical organizations. The MSI proprietary segmental technology has been successfully implemented in manufacturing clean rooms on five continents, and continues to expand – meeting, growing, and facilitating the abilities of device companies around the globe. MSI looks forward to helping your organization provide life-improving devices to your customers, today and tomorrow.

---

### MACHINE DESCRIPTION

---

The Machine Solutions Model 810-A Laminator is a system for the purpose of progressively recovering heat shrinkable materials onto catheter type shafts by means of traversing a thermal nozzle along the length of the materials at a controlled speed over a set length. The materials are suspended vertically, and the thermal nozzles traverse top to bottom to allow the heat shrink to contract as required.

---

#### ***Process Overview***

Parameters are established and programmed via the HMI. Materials are assembled and secured in the product grips. Upon initiation of the process cycle the thermal nozzles extend to the product and then begin traversing the length of the materials to the programmed length. The Shrink Laminator is used to heat shrink material onto up to four catheter assemblies at a time. Variable speed and distance controls allow the shrinking to start at the top or the bottom of the assembly.

The heater array is mounted on the linear actuator; after the heater array has been moved to a convenient loading height, the operator installs the catheters in the grip mechanism. The hot air system is then brought to the correct temperature. When the process is started, the heater array is moved to a start position. The heater assembly is moved out to the catheters, then the heater array is moved down the length of the catheter through as many as six speed zones. The heater array is retracted and returned to the starting position.

The operator can select from a set of 100 recipe files using a barcode scanner. Each file contains the variables used by the process sequence. A passcode is used to control access to the recipe settings, machine settings, and several test screens on the HMI. A passcode of “2694” is hard coded into the passcode logic.

### ***Control System Overview***

The control system consists of an Allen-Bradley CompactLogix PLC A-B and an Allen-Bradley PanelView Plus Standard 7 HMI 10" color display terminal. The PLC controls the operation of the linear actuator, the hot air delivery system, and the cooling jet. The HMI provides the operator the means to monitor and control the operation of the laminator and to set up control parameters.

The PLC is a stand-alone controller not dependent on other PLC resources. The PLC uses Ethernet/IP messaging for the communications between the PLC and HMI. The temperature control of the hot air is provided using a multi-loop controller. The multi-loop controller is connected to the PLC using Ethernet/IP communications.

---

## **SAFETY**

---



**Caution: high voltage. Remove power and use safety precautions when servicing.**



**Caution: hot surface. Contact may cause burn. Allow to cool before servicing.**



**Caution: pinch point. Keep hands and body parts clear while in operation.**

The maximum observed Sound Pressure Level is below 70 dB(A).

Do not use the equipment other than as prescribed. For example: do not attempt to sit on or climb on the equipment, do not place heavy objects or containers of liquid on the machine, do not to insert any foreign objects into the machine and do not attempt to bypass any guards or otherwise operate the machine in any manner other than that in which it is explicitly intended.





## Equipment User Manual

---

### INSTALLATION

---

**Note:** The equipment is not for use with materials that can decompose or ignite below the maximum operating temperature of the machine. Hazards are materials that outgas hazardous substances and or ignite. (400C/750F)

**Note:** This equipment is not for use in an ATEX environment.

1. Place the system on a level, sturdy surface.
2. Lock casters. Casters should be locked at all times when not moving machine.
3. Connect the power cord to the system and then to a 230 VAC 50/60 Hz. 1 Ph. 3-wire Outlet.
4. Connect the air supply hose assembly to the system and then to a clean, dry, and filtered compressed air source.

#### Power Requirements

The laminator is fed from a single 230V/1Ø/2W & GND/25A service. The laminator is equipped with a door-interlock disconnect switch followed by a line filter and a 25A circuit breaker. A neutral connection is required to support the 120VAC heater elements. The maximum draw of the laminator is 3.0kVA or 25A. Please note that phase-angle-fired SCR devices are used to limit each heater's current draw to approximately 5A at 230VAC.

#### Facilities Requirements

1. Voltage: 205-245 VACV 50/60 Hz.
2. Wattage: 1800 max.
3. Air: 60-125 psi, 0.5 CFM, filtered 50 micron or greater, oil and water free.

---

#### **Main Power Disconnect Switch**

The door-interlocked disconnect switch can be locked out for service purposes.

---

#### **Emergency Stop Loop and Hardwired Devices**

A single emergency stop twist-to release switch is connected to a safety relay in the electrical enclosure. The emergency stop switch is wired in series with a red extended head stop switch. Both switches must be released, then the power reset button must be pushed.

When the safety relay is reset, power is applied to the two main contactors. This energizes the linear actuator motor, and the heater power circuits. The blue lamp in the reset button is also illuminated. The PLC, HMI, and the 24VDC inputs remain energized regardless of whether the power contactors are closed.

### ***Overtemperature Controllers***

There are four heater zones on the 810-A Laminator, and each zone has a similar electrical design. Every heating unit includes a mechanical relay that applies power to the semiconductor Solid State Relay (SSR). The state of the heater relay is controlled by the PLC output. Each lane has a separate OverTemp (O/T) thermocouple monitored by the PLC. The O/T temperature must be below the overtemp setpoint before the PLC will allow power to the heater zone.

### **Temperature Controller Uses Ethernet/IP Comms**

The heater temperatures are measured by the multi-zone controller. The controller accepts a setpoint and returns the loop output for each zone using Ethernet/IP communications.

### **Servo Drive(s)**

The drive is run in a position mode using Ethernet/IP resources in the PLC.

### **Remote-In Communication Device**

A remote-in communication device is available for all units that operate with a PLC and HMI only. Remote-in communication device is intended for technical support and maintenance. Remote-in communication is set using Ethernet/IP communications.

### **Optional Light Tower**

Light tower option is not available on all 810A models.

---

### ***Barcode Scanning***

#### **Barcode Scanner Connects to PanelView's USB Port**

A barcode scanner sends data to the USB port on the HMI. When the operator brings up an alphanumeric keypad, the data from the scanner is written to the PLC.

---

### ***Multi-Loop Controller Setup***

#### **Four Control Loops**

The controller reads 4 Type "K" thermocouples and sets 4 SCR power levels. The setpoint for each loop is passed from the PLC to the controller. The temperature and output level are read back by the PLC.

#### **Auto Tuning Initiated by Digital Input 1**

The controller's first digital input is used to put all 4 control zones into an autotuning mode. The digital input is driven by a digital output from the PLC.

#### **Thermocouple Offset**

The PLC's settings support individual offsets that are applied to the controller's thermocouple reading.

## SERVO DRIVES

The drive is run in a position mode using Ethernet/IP resources in the PLC.

## SET UP AND CONFIGURATION

Proper sizing of the **thermal nozzle** and alignment of the tooling are crucial to optimizing process results and repeatability. The following guidelines are the recommended methods; however all applications vary, and several iterations of tooling process development may be required and may not follow all of the recommended guidelines.

**Table 1. Set up and Configuration.**

<b>Thermal Nozzle Diameter</b>	The nozzle diameter should be .187"-.25" larger than the material to be processed.
<b>Thermal Nozzle Width</b>	The width (length of the thermal nozzle should be as long as possible to increase the lamination speed. The standard system will accommodate nozzle widths to 1.0". Customized configurations will be quoted upon request.
<b>Grip/Positioning Nests</b>	The vertical position of the grip assembly should be positioned such that the full lamination length can be accomplished without the catheter touching the floor and with a minimal load height position.

---

## CONTROLS

---

**Table 2. Controls**

Description	Function
Power reset switch	Engages low voltage power and system air.
Power off switch	Disengages low voltage power and system air.
Emergency stop switch	Engages/disengages all system power and air.
Power on indicator	Indicates when system power on by illuminating, off when not illuminated.
HMI	Traverse Parameter interface.
Main power disconnect	Engages/Disengages AC inlet power.
Vee Guide Micrometer	Controls amount of closure of vee guide tooling.
Grip position lock	Locks the grip array position.

---

## CALIBRATION

---

### IMPORTANT NOTES:

1. Calibration must be performed by a certified service, preferably with the system in the location of use. Calibration procedures are the domain of these service providers.
2. Calibration refers to the process of verifying that each of the systems' instruments that controls a process parameter is within manufacturer's specification.
3. Calibration DOES NOT refer to the process of measuring the temperature at the center of the thermal nozzle and "matching" the value to the temperature controller set point.
4. The measured value at the thermal nozzle will rarely match the temperature controller set point and the delta will increase towards the center of the nozzle.
5. For temperature stability verification it is recommended that the air be measured .062"-.093" from the exit point of one of the flow ports. Stability should be +/-5.0 degrees over one hour or at a minimum over the duration of a typical process cycle (customer/product specific) from what is displayed on screen on temperatures from 0 - 500 degrees C. Stability should be +/-10.0 degrees over one hour or at a minimum over the duration of a typical process cycle (customer/product specific) from what is displayed on screen on temperatures from 500 – 750 degrees C.
6. Flow meters must be verified or calibrated since they cannot be adjusted if out of manufacturers specifications.
  - A. Calibrate the temperature controller annually.
  - B. Calibrate the linear actuator speed and distance annually.
  - C. Calibrate the pressure gauge annually.
  - D. Calibrate the Mass Flow Controllers annually if possible (if applicable).

### **Tuning Temperature Controllers**

Refer to the

**AIRFLOW AND TEMPERATURE CONTROLS** section of this manual. (Page 60)

## PARAMETER SETTINGS

### Laminator Settings Variables

The laminator settings are shown in Table 3. Each setting has a minimum and maximum value that restricts the data entry keypad's range. The min/max is user adjustable.

**Table 3. Parameter Settings**

Laminator Setting	Nominal	Range	Description
s00. Temperature Units (0 or 1)	0 = °F	-	Enter a 1 to select °C.
s01. Distance Units (0 or 1)	0 = mm and mm/s	-	Enter a 1 to select inch and IPS.
s02. Actuator Homing Speed	25	10-100	Actuator speed to seek the upper limit switch. Excessive speed into the limit can cause a drive stall trip.
s03. Actuator Fast Speed mm/S	50	10-150	Actuator speed used to find the upper travel limit. Also sets the maximum recipe speed.
s04. Actuator Slow Speed mm/S	10	2-100	Actuator speed to find home position off the upper travel limit.
s05 Actuator Acceleration mm/S/sec	300	50-300	Actuator acceleration for speed changes. The rate is limited by the PLC to a maximum of 1900 steps/mS/sec.
s06. Actuator Steps per mm	5440	5000-6000	Calibration for both axes. Motor has 66536 steps per revolution at the shaft.
s07. Maximum Length	889	500-3000	Sets the tool length. Sets the maximum positions in the recipe.
s08. Minimum Start Position mm	0	0-250	Sets the minimum heater array position relative to the grip elevator so as to avoid tooling crashes when the thruster extends the heater.
s09. Heater Overtemperature Set °F	1000	750-1000	Temperature setting read by the overtemp T/C that disconnects power from the heater.
s10. Max Temperature Setpoint °F	750	0-750	Limits heater setpoint entries.
s11. Temp Deviation Limit °F	±10.0	1-100	Heater deviation band for acceptable temperatures.
s12. Heater Cooloff Temperature °F	120	80-140	Temperature limit for stopping the airflow through the MFC.
s13. Minimum Recipe Speed mm/sec	0.01	0.01-1	Lowest acceptable recipe speed setting.
s14.	0	-	Spare

## Equipment User Manual

s15. Zone MFC Full Scale Flow LPM (if applicable)	47.19	40-80	Calibration value for the heater MFC's.
s16. Zone MFC Deviation Limit LPM (if applicable)	±0.2	0.1-10	Flow deviation limit for heater zone airflow.
s17. Zone MFC Minimum Flow Limit (if applicable)	15	40-80	Minimum allowed flow rate for the heaters.
s18. Grip Full Scale Pr	130	70-140	Full pressure rating of the regulator.
s19. Grip Deviation Limit	±5.0	0.1-100	Allowable grip pressure deviation.
s20.	0	-	Spare
s21. Zone 1 Control TC Offset	0.0	-25 to 25	Temperature offset for heater 1.
s22. Zone 2 Control TC Offset	0.0	-25 to 25	Temperature offset for heater 2.
s23. Zone 3 Control TC Offset	0.0	-25 to 25	Temperature offset for heater 3.
s24. Zone 4 Control TC Offset	0.0	-25 to 25	Temperature offset for heater 4.
s25.	0	-	Spare
s26. Use Thruster (0 or 1)	1=YES	-	Option to disable the heater thruster.
s27. Use Barcode Scanner (0 or 1)	1=YES	-	Option to disable the barcode scanner. Operator must use the scanner to select a recipe.
s28. Brake Release Time Delay secs	0.20	0.1 to 2	Delay to allow the actuator holding brake to release.
s29. to s34.	0	-	Spare
s35. Heater OFF inactivity	3600	0-7200	The value for timer for heaters to shut down after no activity on machine.
s36. Horn On Time	0=OFF	0-3600	Limits length of time horn is on before auto-silencing. Set to ZERO for no horn.
s37. Passcode Timeout	0=NO	0-9999	The user passcode is cleared after this time interval when observing the RUN PARTS screen. If set to zero, there is no timeout.
s38. User Passcode 1		1-99999	Access code for settings and screens.
s39. User Passcode 2		1-99999	Access code for settings and screens.

## PANEL VIEW PLUS HMI DISPLAY DESCRIPTION

The Human Machine Interface (HMI) provides the primary source of operator interaction with the control system. The laminating system is controlled by the PLC. The HMI reads data from the PLC and allows changes to variables in the PLC. The HMI allows the operator to observe the operation of the system.

### Data Entry Keypads

When a numeric value is to be entered, the operator touches the display, which pulls up a keypad like the one shown below. The label of the keypad shows the range that can be entered with the keypad.

A similar keypad is available to enter the name of the recipe.




Figure 1. HMI Keypad



## Main Menu (Screen #01)

The Main Menu screen provides an access point to the remaining screens in the system. Some menu items are hidden unless the passcode has unlocked the HMI. A passcode of “2694” is hard coded into the passcode logic.




Figure 2. Main Menu

Table 4. HMI Display Descriptions

HMI Screen Object Descriptions	
Item	Description
Title	Unit number is read from the PLC.
PLC Status Settings Heater Array Actuator Grip Elevator Actuator Heaters, Solenoid Valves, Alarm History Calibration (if applicable)	Menu Buttons. Made visible when a valid passcode is entered.
previous Run Parts	Menu Buttons. Always visible.
Total Cycles	Numeric Readout. Shows the number of times the laminator process has run to completion.
Unlocked w/ Passcode	Indicator. Shows a valid passcode is active
Enter Passcode to Unlock Screens	Keypad. Used to enter the passcode.

This is how the Main Menu screen appears when there is no passcode present.



**Figure 3. Operator screen**

## PLC STATUS AND HMI SHUTDOWN (SCREEN #02)

Enter the passcode to access this screen from the Main Menu. This screen shows the machine model number and some PLC variables. The HMI application can be shut down from this screen.




**Figure 4. Shutdown Screen**

**Table 5. Shutdown Screen Button Description**

HMI Screen Object Descriptions	
Item	Description
Menu Buttons	Direct access to specified screens.
Model Number	Numeric Readout.
PanelView S/W Revision	Text. Manually changed while creating the application file.
Power On Hours PLC Software Revision Scan Times	Numeric Readouts. Length of time PLC has been running, plus variables to show what software is on the PLC.
PLC Memory Battery OK PLC Memory Battery Low	Indicator. Shows the state of the PLC's memory battery, located under a cover on the left side of the PLC assembly.

## SETTINGS (SCREEN #03)

This screen is used to change Shrink Laminator settings. A passcode must be entered to make the screen accessible from the Main Menu.



**Figure 5. Settings Screen**

**Table 6. Settings Screen Button Description**

HMI Screen Object Descriptions	
Item	Description
Menu Buttons	Direct access to specified screens.
Settings List	List Selector. Use the arrow keys to navigate to a particular setting.
Door Locks Active	Pushbutton. Used to temporarily defeat the door interlocks. Will clear when the passcode is cleared.
Change Setting	Keypad. Used to enter a numeric value for the selected list item.
Min/Max Enable	Pushbutton. Brings up keypads for the minimum and maximum settings used by the Change Setting keypad.
Auto Tune	Menu Button. Access to screen to autotune heaters.
Calibration (if applicable)	Menu Button. Access calibration screen for air flow.
User Passcode 1 & 2	Keypads. Sets the user code as a number from 1 to 99999.
Passcode Timeout	Keypad. Enter zero for no passcode timeout, otherwise the time delay while using the Run Parts screen to automatically clear the code.

## Equipment User Manual

This screen shows the appearance after the Min/Max Enable button is touched. The keypads will disappear if the HMI shifts to another screen.




Figure 6. Limit Settings

Table 7. Limit Screen Button Description

HMI Screen Object Descriptions	
Item	Description
Low Limit High Limit	Keypads. Enter the desired minimum and maximum range for the associated list item.

## AUTO TUNE (SCREEN #04)

Use this screen to initiate an Auto Tune of all four lanes. The push button causes a digital output from the PLC to energize the temperature controller. Be sure to start with a cold heater or room temperature. Start it running to the tuning setpoint, THEN turn on the Start Auto Tune button.





Figure 7. Auto Tune Screen

Table 8. Auto Tune Button Description

HMI Screen Object Descriptions	
Item	Description
Menu Buttons	Direct access to specified screens.
Start Auto Tune	Pushbutton. Starts autotune process
Auto Tune Time Left	Numeric Readout. Allows 10 minutes for auto tuning before automatically clearing the Auto Tune Started output.

## HEATER ACTUATOR (SCREEN #12)

Enter the passcode to access this screen from the Main Menu. The screen is used to exercise the servo motor running the linear actuator.



**Figure 8. Heater Actuator Screen**

**Table 9. HMI Screen Objects - Actuator**

HMI Screen Object Descriptions	
Item	Description
Menu Buttons	Direct access to specified screens.
Hand/Off/Auto	Interlocked Pushbuttons. Set to AUTO to run the process. Set to HAND to allow use of the controls on this screen. AUTO mode is forced when the CYCLE START button is pushed.
Ready for Command	Indicator. Shows the state of the Actuator control sequence.
Actuator Position Actuator Speed	Keypads with Numeric Readout Overlays. Used to monitor and to manually enter position and speed setpoints.
Encoder Position Encoder Speed	Readouts. The Wire Draw Encoder is zeroed when the actuator is homed. The speed is the 1 second count difference.



**Table 10. Heater Actuator Button Description**

Heater Array HMI Screen Object Descriptions	
Item	Description
Homed OK Home Limit Active Neg Limit Active Pos Limit Active Drive Enable Out AKD Not Fault Relay	Indicators. On/Off status.  PLC digital output AKD relay output.
Fast Jog Selected Touch for Slow	Pushbutton. Toggles between the fast and slow jog speeds.
Jog Up Jog Down	Pushbuttons. Used to manually move the step motor.
Home to Upper Limit	Pushbutton. Causes the actuator to run to the left limit, then sets the zero offset just as the limit switch comes back on.
Move to Start Move to Load Move from Keypad	Pushbuttons. Once the actuator is homed, these buttons will cause absolute moves from the recipe settings or the keypad.
Stop	Pushbutton. Sends the stop motion command.
Reset	Pushbutton. Restarts the stepper control sequence.



## HEATERS AND HEATER AIRFLOW (SCREEN #13)

Enter the passcode to access this screen from the Main Menu. This screen is used to test the heating controls.





Figure 9. Heaters and Heater Airflow Screen

**Table 11. Heater Screen Button Description**

<b>HMI Screen Object Descriptions</b>	
<b>Item</b>	<b>Description</b>
Menu Buttons	Direct access to specified screens.
Heater Status	Indicators. Shows the heater/airflow status as defined in Section <b>Heater Overtemperature Control page 60</b> .
Hand/Auto	Interlocked Pushbuttons. Set to AUTO to run the process. Set to HAND to allow use of the controls on this screen. AUTO mode is forced when the Run Parts RUN button is pushed.
Heater Temp Heater Setpoint Loop Output Overtemp T/C reading	Keypad w/ Numeric Readout Overlay. Used to manually change the temperature setpoint.
Heater OFF touch for ON	Pushbuttons. Toggles the heater run request on and off. Heat will not be applied unless all interlocks are OK.
Flowrate Reading ( <i>if applicable</i> ) Flowrate Setpoint ( <i>if applicable</i> )	Keypad w/ Numeric Readout Overlay. Used to manually control the Mass Flow Controller (MFC).
Airflow OFF touch for ON ( <i>if applicable</i> )	Pushbuttons. Toggles the MFC on and off. The MFC will stay on if the heater is above the cool off temperature. The MFC auto-starts when the heater is turned on.

## PNEUMATICS AND VALVES (SCREEN #14)

Enter the passcode to access this screen from the Main Menu. This screen is used to test the pneumatic components.



**Figure 10. Pneumatics and Valve Screen**

**Table 12. Pneumatics Screen Button Description**

HMI Screen Object Descriptions	
Item	Description
Menu Buttons	Direct access to specified screens.
Main Air Valve Thruster Vee Guide Door Lock Solenoid Grip Pressure Regulator Light Tower (if applicable)	Interlocked Pushbuttons. Use MANUAL and OFF to test the devices.
Thruster Extend Sensor Door Lock Inputs 1 & 2 Mandrel Present Sensors	Indicators. Shows on/off status.
Grip Pressure Read	Keypad overlaid with readouts. Used to enter a temporary setpoint for testing on this screen.

## CALIBRATION (SCREEN #15) (IF APPLICABLE)

This screen is used by the operator to start and stop the laminator air flow calibration process.




Figure 11. Airflow Calibration Screen

Table 13. Calibration Screen Objects

HMI Screen Object Descriptions	
Item	Description
Menu Buttons	Direct access to specified screens.
Select Air Flow: Air Flow 1 Air Flow 2 Air Flow 3 Air Flow 4	Indicator. Grey shows air flow lane selected.
Calibration Failed – press Cancel to Retry	Indicator. Shows the state of the air flow control sequence and displays instruction messages.
Flow #: Flowrate Setpoint	Numeric entry box for calibration setpoint.
Flow #: Measured Flowrate	Numeric entry box for calibration flow reading.
Start Calibration Continue Accept Calibration Cancel	Pushbuttons. Accessible to start, continue, cancel, and accept calibration.

## RUN PARTS (SCREEN #10)

This screen is used by the operator to start and stop the laminator and monitor the process.




Figure 12. Run Screen

Table 14. HMI Screen Objects

HMI Screen Object Descriptions	
Item	Description
Menu Buttons	Direct access to specified screens. RECIPE EDIT and RECIPE SELECT are only visible with a good passcode.
Run Recipe #1 [NAME] Run Modified Recipe	Two-state indicator. Shows the recipe number and name. If the recipe has been changed, will show MODIFIED recipe in yellow.
Alm##. Warn##.	Multistate Indicators. Indicators cycle through all alarms and warnings present. See the lists in <b>ALARMS</b> section and <b>WARNINGS</b> section for descriptions.
ERROR: Tripped on Alarm	Multistate Indicator. Shows the state of the Master Control Sequence.
Heater Array Ready for Command	Indicator. Shows the state of the Actuator control sequence.
Speed, Position	Numeric Readouts. Shows the actuator speed and position.



## Equipment User Manual

---

**Table 15. HMI Screen Objects - Run Screen**

<b>HMI Screen Object Descriptions (Run Parts)</b>	
<b>Item</b>	<b>Description</b>
No Part Present (if applicable)	Indicators. Shows the part present sensor/grip state.
Temperature OK	Indicator (each heater). Shows the heater/airflow status as defined in Section <b>Heater Overtemperature Control</b> , page 60.
501 °F, set 500 °F 15.0 LPM, set 15.0 (if applicable)	Numeric Readouts (each heater). Shows the setpoint and actual value for the temperature and airflow.
CYCLE START CYCLE STOP	Pushbuttons. Used to start and stop the laminator sequence.
Horn Silence (if applicable)	Pushbutton. Appears when an alarm is active. Touch to silence the horn.
Process Time	Elapsed time for the run. Resets when the next run starts.
Runs to xxxx mm	Position of heater array when the run will finish.
Encoder Position	Wire Draw Encoder position reading, where the encoder is zeroed when the actuator is homed.
Encoder Speed	Counts received in 1 second, then converted to a speed reading.

### **CYCLE START Pushbutton**

This button is used by the operator when prompted to advance the Master Control Sequence. The operator will be prompted to home the linear actuator, scan a barcode, load the mandrels, and run the process.

### **CYCLE STOP Pushbutton**

This button is used to reset alarms. If the laminator detects any of the alarms described in Table 19, the CYCLE STOP button is tapped to release the alarm.

Holding the CYCLE STOP button down for 2 seconds through the HMI forces a full Master Control Sequence reset.

### Run Parts Screen without Passcode

The Run Parts screen is slightly different when the passcode has not unlocked the controls. The “Recipe Selected w/ Scanner Only” label shows when the settings require the use of the barcode scanner to select recipes.




Figure 13. Run Parts Screen

### Passcode Cleared on Laminator Power Up

Note that a setting is available to automatically clear the passcode after a length of time. The passcode is also cleared when power is first applied to the laminator (first pass of the PLC's program).



## RECIPE SETTINGS AND DESCRIPTIONS

Up to 100 recipes can be stored in the PLC. The operator optionally uses a barcode scanner to select a recipe. When a valid passcode is entered, the recipe can be selected from a list. The passcode is required to make alterations and to save a recipe in the database.

Many recipe entries are restricted by the settings noted above. For example, heater temperature is limited by setting s10.

The recipe is a collection of setpoints that are directly copied to the machine controls when the recipe is selected.

### Alternate Units

Speed, distance, and temperature may be shown in alternate units. The recipe is stored in native units of mm and °F.

**Table 16. Alternate Recipe Units**

Recipe Settings	Units	Range	Description
Name	ASCII	-	Name stored with the recipe, entered using the alphanumeric keypad of the HMI.
Date	ASCII	-	Date of file storage.
Barcode	ASCII	-	Barcode string captured and associated with this recipe
Temperature	°F	0 to 700 [s10]	Heater operating temperature.
Load Position	mm	0 to 2750 [s07]	Position for grip elevator and heater array for loading and unloading.
Heater to Grip Offset	mm	0-508	Offset applied when the heater array is homed to the bottom of the grip assembly. For example, an offset of 25.4 mm causes the 0 mm position of the array to be one inch below the elevator.
Direction (pushbutton)		Positive Down or Negative Up	Specifies whether the heating direction is from the top to the bottom of the catheter or starts at the bottom and goes up.
Start Position	mm	Computed value	Positive Down: Minimum and Maximum is Grip Start plus Min Start Position [s08]. Negative Up: Minimum is Grip Start plus sum of zone lengths. Max is Max Length [s07].
Start Dwell Time	secs	0 to 9999	Time to wait at the start position when the heater is extended. Note that Cooling Dwell Time at end of run is set by [s34]
End Dwell Time	secs	0 to 9999	Time to wait at the end position when the heater is retracted.

## RECIPE SELECT (SCREEN #20)

Access to this screen requires the passcode.

Up to 100 recipes can be stored on the Shrink Laminator. The buttons for saving a recipe are only visible when the passcode is entered.

If the barcode scanner is used, the 100 files will be searched for a match. The first recipe that has a match will be loaded as the current recipe.




Figure 14. Recipe Select Screen

Table 17. Recipe Screen Button Description

HMI Screen Object Descriptions	
Item	Description
Menu Buttons	Direct access to specified screens.
Enter Recipe File Number	Keypad. Used to set the file number for recipe storage.
Save Recipe to File #1.	Pushbutton. The file number is shown on the button. When touched, the user has 5 seconds to touch a CONFIRM button to complete the save.
100 Recipes Available [Recipe Names on List]	List Selector. Use the middle row of navigation keys to point to the desired recipe. The recipe will be loaded when the screen is changed.

## RECIPE EDIT (SCREEN #21)

Enter the passcode to access this screen from the Main Menu.

This screen is used to change the control settings for the laminator sequence. Each of the variables can be changed by touching the display.

21 Edit Recipe #2 MOTION TEST DOWN		
Recipe Name MOTION TEST DOWN	Barcode for this Recipe: 258631	Load Pos'n: 100.00 mm
Temperature: 300 °F	Direction: Positive Down	Heater Start Pos'n: 0.00 mm
Heater to Grip Offset: 0.00 mm (applied when Array is Homed)	Zone 1: 50.80 mm	Speed 1: 25.400 mm/S
Dwell Time: 2 sec	Zone 2: 25.40 mm	Speed 2: 27.940 mm/S
Grip Pressure: 25 PSIG	Zone 3: 25.40 mm	Speed 3: 25.400 mm/S
	Zone 4: 25.40 mm	Speed 4: 25.400 mm/S
	Zone 5: 25.40 mm	Speed 5: 25.400 mm/S
	Zone 6: 152.40 mm	Speed 6: 38.100 mm/S
Main Menu	previous	Recipe Select
		Run Parts

**Figure 15. Recipe Edit Screen**

**Table 18. Recipe Edit Screen Button Description**

HMI Screen Object Descriptions	
Item	Description
Menu Buttons	Direct access to specified screens.
Edit Recipe # [NAME]	Shows the currently loaded recipe file number and name.
Recipe Name	Alphanumeric keypad. Touch to enter a name for the recipe.
Barcode for this Recipe	String Readout. Shows the associated barcode for the recipe
Touch to Capture Barcode Scan Barcode Now!	Pushbutton. Touch to add or change the barcode for the recipe. Button will revert when a code is scanned or after leaving the screen.
Temperature through Speed 6, others	Keypads. Each keypad has a minimum and maximum value. The functions of each parameter are reviewed in above sections.
Direction: Positive Down or Negative Up	Pushbutton. Negative up selection starts run cycle to traverse from the bottom moving in the up direction. Positive down selection starts run cycle to traverse from the top moving in the down direction

---

## HMI SUPPORT SCREENS

---

The Information Message Banner is triggered by the PLC. The banner automatically closes after 3 seconds, or the CLOSE button can be touched.




Figure 16. Shutdown Screen

### Alarm Banner Overlay

The Alarm Banner is triggered by the PLC from the list described in Table 19. Use the CLOSE button to remove the banner.

If the banner legend is blank, an alarm occurred but has been restored. Check the Alarm Log to determine the specific alarm that triggered the banner.



**Figure 17. Alarm Banner**

### **Alarm Log**

The Alarm Log holds a record of the last 128 alarm occurrences. The alarm message is saved along with the time the alarm was tripped.

The time is recorded from the HMI's internal real-time clock. Use the hour/minute/seconds buttons on the PLC Status screen or shut down the application to adjust the HMI clock's date.

## Equipment User Manual

Access to this screen is passcode protected.




Figure 18. Alarm Log

## ALARMS

The PLC monitors the laminator for multiple alarm conditions. When an alarm occurs, it brings up an alarm overlay banner on the HMI. The HMI stores the alarm time and the alarm text in an alarm log.

**Table 19. Alarm Message Description**

Alarm Message	Comments
Alm00. PLC I/O Module Failure	Fault on one or more Compact I/O modules
Alm01. Eurotherm Mini8 Comms Fault	Ethernet communications not OK with temperature controller
Alm02.	Spare
Alm03.	Spare
Alm04.	Spare
Alm05.	Spare
Alm06. Eurotherm Mini8 Program Fault	Mini8 Temp Controller OK bit not set
Alm07.	Spare
Alm08.	Spare
Alm09. Heater Array Drive Fault	Hardware OK signal lost for heater array
Alm10. Heater Broken Thermocouple	No thermocouple report from Mini8
Alm11. Heater Overtemp Controller Trip	PLC thermocouple exceeded shutoff temperature.
Alm12. Heater Temp Deviation Trip	Left deviation band while processing
Alm13. Heater Airflow Trip	Zone airflow switch OFF while processing
Alm14.	Spare
Alm15. Thruster Extend Failure	Extend limit not made
Alm16. Thruster Retract Failure	Extend limit stayed on
Alm17.	Spare
Alm18. Heater Array Drive Comms Fault	Ethernet comms failed
Alm19. Light Curtain Violated while Processing	Curtain violated while running
Alm20. Travel Limit Hit while Processing	Heater array hit overtravel sensor
Alm21. to Alm31.	Spares

### Alarms while Processing

If an alarm occurs during lamination, the thruster is immediately retracted, and the heater array motion is stopped. The operator must push CYCLE STOP to clear the alarm.

After the alarm is cleared, the heater array and grip elevator are brought to the load position so the faulted parts can be removed.

### Airflow and Temperature Alarms

The airflow and temperature alarms are enabled only when processing.

## WARNINGS

Warnings are shown on the HMI “Run Parts” screen as an aid to the operator.

**Table 20. Warning Message Description**

Warning Message	Comments
Warn00. Controls Not Reset	Safety relay is not reset.
Warn01.	Spare
Warn02.	Spare
Warn03.	Spare
Warn04.	Spare
Warn05. Light Curtain is Violated ( <i>if applicable</i> )	Light curtain has been broken/trespassed.
Warn06. Doors Interlock is Bypassed	Passcode needed to access the bypass button on the Settings screen.
Warn07.	Spare
Warn08. Passcode has Unlocked Controls	Correct password has been entered. Controls are unlocked.
Warn09. Auto Tuning in Progress	10-minute tuning time in effect.
Warn10. to Warn30.	Spares
Warn31. PLC Memory Reloaded from EEPROM!	PLC memory fault has caused the program to reload from the SD card. Also logged to the alarm log.



---

## LAMINATOR SETTINGS AND RECIPE CONTROLS

---

The settings for the laminator are adjustments that are rarely altered. The recipe controls allow easy process development with storage of the recipe when a good process has been established.

### **Alternate Display Unit**

The laminator's native units for distance are millimeters. The native temperature units are degrees Fahrenheit.

The HMI is organized to show the user's preferred units. For each distance, speed, and temperature on the operating screens, one of two text strings are displayed.

Distance:	mm	or	inch
Speed:	mm/S	or	IPS
Temperature:	°F	or	°C

The settings table and internal recipe storage is maintained in mm and °F.

### **Passcode Required to Change Settings**

Changes to the settings require the entry of a user passcode. Two different user passcodes are adjustable in the settings. A passcode of "2694" is hard coded into the passcode logic.

The passcode is cleared after a time delay passes when the HMI is displaying the Run Parts screen. The time delay is adjustable in the settings and can be defeated by setting the timeout to ZERO.

### **Laminator Settings Variables**

The laminator settings are shown in the table below. Each setting has a minimum and maximum value that restricts the data entry keypad's range. The min/max is user adjustable.

## Equipment User Manual

**Table 21. Laminator Settings Variables**

Laminator Setting	Nominal	Range	Description
s00. Temperature Units (0 or 1)	0 = °F	-	Enter a 1 to select °C.
s01. Distance Units (0 or 1)	0 = mm and mm/s	-	Enter a 1 to select inch and IPS.
s02. Actuator Homing Speed	25	10-100	Actuator speed to seek the upper limit switch. Excessive speed into the limit can cause a drive stall trip.
s03. Actuator Fast Speed mm/S	50	10-150	Actuator speed used to find the upper travel limit. Also sets the maximum recipe speed.
s04. Actuator Slow Speed mm/S	10	2-100	Actuator speed to find home position off the upper travel limit.
s05 Actuator Acceleration mm/S/sec	300	50-300	Actuator acceleration for speed changes. The rate is limited by the PLC to a maximum of 1900 steps/mS/sec.
s06. Actuator Steps per mm	5440	5000-6000	Calibration for both axes. Motor has 66536 steps per revolution at the shaft.
s07. Maximum Length	889	500-3000	Sets the tool length. Sets the maximum positions in the recipe.
s08. Minimum Start Position mm	0	0-250	Sets the minimum heater array position relative to the grip elevator as so to avoid tooling crashes when the thruster extends the heater.
s09. Heater Overtemperature Set °F	1000	750-1000	Temperature setting read by the overtemp T/C that disconnects power from the heater.
s10. Max Temperature Setpoint °F	750	0-750	Limit's heater setpoint entries.
s11. Temp Deviation Limit °F	±10.0	1-100	Heater deviation band for acceptable temperatures.
s12. Heater Cooloff Temperature °F	120	80-140	Temperature limit for stopping the airflow through the MFC.
s13. Minimum Recipe Speed mm/sec	0.01	0.01-1	Lowest acceptable recipe speed setting.
s14.	0	-	
s15. Zone MFC Full Scale Flow LPM (if applicable)	47.19	40-80	Calibration value for the heater MFC's.
s16. Zone MFC Deviation Limit LPM (if applicable)	±0.2	0.1-10	Flow deviation limit for heater zone airflow.
s17. Zone MFC Minimum Flow LPM (if applicable)	15	40-80	Minimum allowed flow rate for the heaters.

## Equipment User Manual

Laminator Setting	Nominal	Range	Description
s18. Grip Pressure Regulator Full Scale PSIG	130	70-140	Full pressure rating of the regulator.
s19. Grip Pressure Deviation Limit PSIG	±2.0	0.1-100	Allowable grip pressure deviation.
s20.	0	-	Spare
s21. Zone 1 Control TC Offset °F	0.0	-25 to 25	Temperature offset for heater 1.
s22. Zone 2 Control TC Offset °F	0.0	-25 to 25	Temperature offset for heater 2.
s23. Zone 3 Control TC Offset °F	0.0	-25 to 25	Temperature offset for heater 3.
s24. Zone 4 Control TC Offset °F	0.0	-25 to 25	Temperature offset for heater 4.
s25.	0	-	spare
s26. Use Thruster (0 or 1)	1= YES	-	Option to disable the heater thruster.
s27. Use Barcode Scanner (0 or 1)	1= YES	-	Option to disable the barcode scanner. Operator must use the scanner to select a recipe.
s28. Brake Release Time Delay secs	0.20	0.1 to 2	Delay to allow the actuator holding brake to release.
s29. to s34.	0	-	Spare
s35. Heater OFF Inactivity Delay Time secs	3600	0-7200	Seconds to wait without a process run before shutting off the heaters.
s36. Horn ON Time secs	60	0-3600	Limits length of time horn is on before auto-silencing. Set to ZERO for no horn.
s37. Passcode Timeout secs	0= NO	0-9999	The user passcode is cleared after this time interval when observing the RUN PARTS screen. If set to zero, there is no timeout.
s38. User Passcode Code 1	1	1-99999	Access code for settings and screens.
s39. User Passcode Code 2	2	1-99999	Access code for settings and screens.



## Equipment User Manual

---

### SYSTEM OPERATION

---

1. Position product within vee grip.
2. Toggle corresponding grip switch to close grip.
3. Repeat for all positions to be utilized.
4. Close cabinet door.
5. Touch "START" on HMI
6. Upon completion of the cycle open the cabinet door, secure the product, and deactivate the corresponding grip switch to release the product.

## TERMS AND DEFINITIONS

**Table 22. Terms, Definitions and Descriptions**

Term	Definition
A-B	Allen-Bradley
PVP	Allen-Bradley touchscreen family
Ethernet/IP	Communications protocol for A-B automation equipment
HMI	Human Machine Interface providing an operational interface for a system.
I/O	Input and Output signals a PLC
PLC	Programmable Logic controller
PID	Proportional, integral, and derivative control method used to maintain the heater temperature at the desired setpoint.
MFC	Mass Flow Controller, used to control airflow through the heater element.
SSR	Solid State Relay. The Shrink laminator uses a phase-angle-fired SSR to control the current sent to the heater element.
O/T	Overtemp Controller. Separate hardwired device that monitors the heater body for acceptable temperature.
LPM	Liters per minute. Heater zone flow rates are manually adjusted.
Mini8	Eurotherm's Ethernet/IP compatible multi-zone temperature control.
UDT	User Data Type. RSLogix5000 method of organizing data.
AOI	Add-On Instruction. Custom RSLogix5000 instruction.
SCR	Silicon Control Rectifier. Provides maximum control of your heat process, and it can extend heater life.



## Equipment User Manual

---

---

### MAINTENANCE

---

**Note:** Perform these steps **ONLY** when the nozzles are at room temperature.

**Note:** Ensure the machine is unplugged for any servicing or maintenance work.


#### **Cleaning**

**Note:** All products are cleaned before they are shipped; however, it is recommended that the user clean the exterior of the machine before use.


Use only 100% Isopropyl alcohol to clean this machine.

### Replacing Thermal Nozzles

1. Loosen lower-rear set screws on heat shield.
2. Remove upper-front button head screws from heat shield and carefully remove heat shield assembly.
3. Loosen the set screw at the side of the nozzle adapter.
4. Slide the nozzle off the heater shield while simultaneously pulling out the thermocouple connector.
5. Install the replacement nozzle by sliding it completely onto the heater shield.  
**Note: Ensure nozzle is fully seated against overtemp bracket.**
6. Tighten the lock set screw.
7. Insert the thermocouple connector into the jack.




**Figure 19: Replacing Thermal Nozzles – Remove Heat Shield**



**Figure 20: Replacing Thermal Nozzles – Nozzle Set Screw**

### Exchanging Vee Guide/insert(s)

1. Remove the fasteners securing the guide to the actuation rail.
2. Position the replacement guide on the rail and align with the mounting holes.
3. Install the fasteners.




**Figure 21: Exchanging Vee Guide/Inserts**




### **Replace Heating Element(s)**

1. Jog the heater array down to approximately mid-stroke.
2. Remove the fasteners of the heater enclosure top panel.
3. Disconnect the heater power quick-connect terminals.
4. Loosen the heater retainer fastener.
5. Disconnect the heater airline.
6. Pull the heater retainer away from the heater boot.
7. Slide the heater element completely rearward until free of the assembly.
8. Connect airline and fasten heater retainer.
9. Connect heater power quick-connect terminals to heater.
10. Fasten screws on heater enclosure top panel.



**Figure 22: Replace Heating Elements - Top Cover Removal**




**Figure 23: Replace Heating Elements – Remove/install Heater**


### Replace Heater Power Controller

Note: Please contact Machine Solutions for part replacement.

1. Disconnect system power and air.
2. Locate the power controller(s).
3. Using a medium size flat blade screwdriver open the terminal covers.
4. Loosen terminals **1/L1**, **3/L2**, **2/T1** and **4/T2** at the top front and rear of the controller.  
Note: Keep track of wire locations. For schematics, contact Machine Solutions.
5. Pull the signal connector from the front of the controller.
6. Remove the ground connection using a flat blade screwdriver.
7. Using a flat blade screwdriver, pull out the DIN rail lock at the bottom-front of the controller.
8. Replace the power controller and secure it by pushing in the DIN rail lock.
9. Re-install parts and wires from previous steps.
10. Using a small flat blade screwdriver, turn rotary switch COUNTER-CLOCKWISE for 40 full turns.
11. Cycle machine power.



**Figure 24: Replace Heater Power Controller - Locate Controller**




**Figure 25: Replace Heater Power Controller**

### Aligning Tooling

**Note:** Alignment should be performed on a prepared product subassembly. Alignment **MUST** be performed with system power off and heads at ambient temperature.

1. Open the cabinet door.
2. Remove heat shields as shown in "Replacing Thermal Nozzles".
3. Secure a .062"-.25" O.D. x 12" mandrel in grip #1
4. Manually extend the heater array assembly.
5. Adjust the vee closure micrometer as required until the vee guides are close but not touching the mandrel.
6. Inspect and compare the gap between the left and right vee guide.
7. Loosen the vee grip actuator fasteners and adjust left or right until the vee guide gap around the mandrel is reasonably even then secure the grip actuator fasteners.
8. Loosen the nozzle assy. mount fasteners and adjust the nozzle assy. left or right, X-Axis, until the nozzle is reasonably centered around the mandrel, then secure the fasteners.
9. Adjust the Y-Axis until the nozzle is reasonably centered with the thermal nozzle.



**Figure 26: Aligning Tooling**

---

## SYSTEM SPECIFICATIONS

---

**Table 23. System Specifications**

<b>Description</b>	<b>Range</b>	<b>Resolution</b>	<b>Accuracy</b>
Temperature	250-750° F	1.0 deg.	± .25% F.S.
Grip Pressure	3-100 psi	2.0 psi	± 1.5% F.S.
Length	1-1778 mm 1-2055 mm 1-2550	0.1 mm	± 0.2mm
Speed	0.1-20 mm/sec	0.1 mm/sec	± 5%
Airflow	15-35 LPM	1.0 LPM	± 1.0% F.S.

## CRITICAL PARTS LIST

**Table 24. Critical Spare Parts (contact Machine Solutions for current Price and delivery)**

Item	P/N	Description
8.6.1	1330445-003	4-way valve 24 VDC
8.6.2	1145807-001	Heater power SCR
8.6.3	1343250-001	2-way pneumatic valve
8.6.4	1344963-001	4-way toggle valve
8.6.5	1145607-001	Bar Code Scanner (optional)
8.6.6	1145631-001	Touch Screen (HMI version only)
8.6.7	1145596-001	PLC (HMI version only)
8.6.8	1145622-001	Motor Drive (HMI version only)
8.6.9	110254-001	Heating element
8.6.10	1143786-003	8mm proximity sensor PNP NO (HMI version only)
8.6.11	1143771-001	12mm proximity sensor PNP NO (HMI version only)
8.6.12	1143771-003	12mm proximity sensor PNP NC (HMI version only)
8.6.13	1143287-001	DPDT Relay (HMI version only)
8.6.14	1143133-001	0.125" Thermocouple (HMI version only)
8.6.15	1143992-001	0.062" Thermocouple
8.6.16	1345564-001	Mass Flow Controller (digital flow version)
8.6.17	1148096-001	Keypad HMI (keypad version)
8.6.18	1148103-001	Drive Controller (keypad version)
8.6.19	1144980-001	Limit Switch (keypad version)
8.6.20	1150355-001	Prox. Sensor (keypad version)
8.6.21	1146420-001	Temp Controller (keypad version)

## DIAGNOSTICS (TROUBLESHOOTING)

**Table 25. Diagnostics**

	Issue	Possible Causes	Solution
8.7.1	Temperature not stable	Thermal Nozzle replaced. Thermocouple loose. MFC flow fluctuation ( <i>if applicable</i> ). Tuning on SCR.	Auto-tune Re-install thermocouple. Verify air flow. Contact Machine Solutions.
8.7.2	S.br (sensor break)	Thermocouple disconnected. Disconnect of wire between controller and thermal nozzle.	Verify thermocouple/wire connections.
8.7.3	No heat at nozzle	Heater air flow too low. Defective heating element. Defective power control.	Increase air flow. Replace heating element. Contact Machine Solutions.
8.7.4	System will not power on.	Emergency stop switch depressed. IEC power cord not fully connected.	Rotate switch knob to engage. Verify installation.

### Ethernet Connections and IP Addresses

These IP addresses are used for system communications. All subnet masks are 255.255.255.0

**Table 26. Ethernet Connections and IP Addresses**

Name	Address	Description
CompactLogix	192.168.1.150	PLC's Ethernet/IP communications port.
PanelView Plus CE 1000	192.168.1.151	PVP HMI communications port.
Eurotherm Mini8	192.168.1.153	Multi-zone temperature controller port.
Heater Array AKD Drive	192.168.1.155	Ethernet/IP controlled servo drive.

## APPENDIX

### Sequences of Operation

#### Master Control Sequence

The master control sequence boots up the laminator subsystems and serves as the main operator guide for the laminating operation.

Any alarm will cause the sequence to jump to State 31. Touch the CYCLE STOP button to release the alarm. An alarm will retract the heater assembly and stop the actuator motion.

Holding the CYCLE STOP button down for 2 seconds resets the master control sequence.

**Table 27. Master Control Sequence**

State	Master Control Sequence Label	Comments
0	Control System Full Reset	User must release the RESET button to leave this step. Door lock is released.
1	Controls Not Reset - Push POWER RESET Button	Master Control Relay is not reset. Clear the emergency stop and push the blue reset button
2	STARTUP: Opening Main Air Valve	Allows 2 seconds for air to fill system.
3	STARTUP: Retracting Heaters	Heater must be retracted before moving actuator
4	STARTUP: Touch CYCLE START to Lock Door	n/a
5	STARTUP: Waiting for Door to Close	Door lock is de-energized to latch the door. A signal is received when the latch is made. Note that the MAINTENANCE door is also guarded along with the PROCESS door.
6		N/A
7	READY: Touch CYCLE START to home Actuator	Homing starts when doors are closed.
8	HOMING: Homing Grip Elevator	N/A w/o grip elevator. Starts the grip elevator towards the upper limit. Home (zero) position is just off the upper fixed travel limit. Delays 5 secs before going to the next step.



## Equipment User Manual

State	Master Control Sequence Label	Comments
9	HOMING: Homing Heater Array	Moves the heater array actuator up until the travel limit on the upper side of the heater array is sensed, then moves to the home (zero) position just after the switch is restored. This upper limit switch is also the lower travel limit for the elevator.
10	HOMING: Move Actuator to Load Position at [Load Posn]	Moves the heater array down to the height specified in the recipe. If an alarm has occurred during processing, jump to Step 27 so that parts can be removed. The door is unlocked after this step.
11	STARTUP: Use Scanner to Select Recipe	When every power is reset, the operator must select a recipe using the barcode scanner. If the passcode is in effect, pushing the CYCLE START button bypasses this step. Door lock is released.
12	STARTUP: Turn on at least one Heater and install the Mandrel	The operator must turn on a heater and load the mandrel to proceed.
13	STARTUP: Bringing Loaded Heaters up to Temperature	Turns on the MFC at the recipe flowrate. For each heater, the PLC waits for the airflow reading to match the setpoint, then turns on the heater's mechanical relay. For each heater, the PLC turns on the SSR to send power to the heater. The sequence will stay on this step until all temperatures have stabilized around the setpoint.
14	LOAD: Load Parts or touch CYCLE START to run empty	The cycle may be run without parts for testing. This step is skipped if parts are present.

## Equipment User Manual

State	Master Control Sequence Label	Comments
15	LOAD: Touch CYCLE START to Lock Door	Releases the door lock solenoids.
16	LOAD: Waiting for Door to Close	Holds here until the doors are closed, then go to Step 18.
17	READY: touch CYCLE START to Move Actuator to Start Position	Ready to move to start position
18	RUN: Move Heaters to [Heater Start]	Moves actuators to initial position.
19	READY: touch CYCLE START to Run Parts	Touching CYCLE START begins the laminating cycle. Touch CYCLE STOP to unlock the door. This jumps the sequence to Step 14.
20	RUN: Close Vee Guides, Extend Heater, Dwell at Start for [Dwell Time Left]	Thrusts the heater array to the parts. Closes the Vee Guide. Counts down the dwell time at the start position.
21	RUN: Zone [x] at Speed [y] for Length [z] (runs to [End Posn])	Display while the part is processing. Moves the heater array actuators through the six recipe zones at the zone speed to the calculated end position.
22	RUN: Retract Heaters	Pulls heater back from product.
23	WAITING AT END OF RUN: Touch Cycle Start to Finish	Wait for Operator option is SET in the settings.
24	END OF RUN: Waiting for Door to Close	Waiting for door to close.
25	RUN: Move Actuator to Load Position at [FastJogSpeed]	Moves to start position.
26		N/A
27	UNLOAD FAILED PARTS: Open Door and Remove ALL Parts Now touch CYCLE START to resume	Waits at this state until all grips are opened. Jumps back to Step 14 when the grips are cleared. Door lock is released.
28	UNLOAD: Remove Finished Parts - Touch Cycle Start to Proceed	Returns to Step 14 when CYCLE START is pushed. Door lock is released.
29		N/A
30		N/A



## Equipment User Manual

State	Master Control Sequence Label	Comments
31	ERROR: Tripped on Alarm - Touch CYCLE STOP to reset	Alarm state. Stops motion and retracts thruster. Door lock is released.

## SERVO MOTOR CONTROL SEQUENCE

The servo motor uses a set of add-on instructions. The PLC uses a control sequence to send commands in the correct order. The control sequence below allows for the operator to manually move the servo motor and supports automatic operation.

The step number drives a multi-state indicator on the Run Parts screen.

**Table 28. Servo Motor Control Sequence and Description**

Step	State Label	Description
0	Servo Sequence Reset	Reset by master sequence.
1	Wait for AKD Comms OK	PLC must have good ethernet comms to the AKD drive.
2	Wait for Controls Reset	Power must be reset.
3	Shut Down Drive	Stops the drive.
4	Motor Selected OFF	HAND/OFF/AUTO control set to OFF.
5	Reset Shutdown	Clears shutdown mode of drive.
6	Reset Drive Faults	Clears drive faults.
7	Enable Drive	Turns on PLC output for drive enable/reset.
8	Ready for Command	Wait for manual or auto command.
9	Homing: Find Upper Limit	Fast jog to the upper travel limit
10	Homing: Jog Off Upper Limit	Slow jog down to find electrical zero.
11	Set Homed OK	Immediate home. Home offset applied in logic.
12	Jogging Down	Positive Jog.
13	Jogging Up	Negative Jog.
14	Hold Motion	Stops motion.
15	Relative Move	Not used
16	Move to [Position Reading]	Absolute move, used for START and LOAD moves.
17	Attempt N159 Error Recovery	Slight jog to clear communication error. Three attempts allowed.
18-23		Not used
24	ERROR: Positive Limit Hit	Manual jog.
25	ERROR: Negative Limit Hit	Manual jog
26	ERROR: Positive Limit Trip	Unexpected hit.
27	ERROR: Negative Limit Trip	Unexpected hit.
28	ERROR: Home Not Found	Not used
29	ERROR: No Hardware Enable	Not used
30	ERROR: Motor Software Error	Servo command error detected.
31	ERROR: Motor Hardware Fault	Fault relay from drive is OFF.

---

## AIRFLOW AND TEMPERATURE CONTROLS

---

The process heaters do not use a control sequence, but each heater has multiple interlocks to allow good temperature control.

All four heaters have the same control structure.

### **Air Flow Controls**

A manual flow control valve is supplied for each of the four zones. The air pressure switch must be activated before power is allowed to the heater.

### **Heater Overtemperature Control**

The PLC monitors a second thermocouple on the body of the heater. The PLC will allow the heater power relay to close if the temperature is below the O/T unit's setpoint.

### **Multi-Loop Temperature Controller**

The Eurotherm Mini8 Loop Controller runs all four heaters. Each loop physically consists of a Type "K" thermocouple and a 4/20 mA heating output. Each loop uses a temperature setpoint to determine how much heating to apply.

The PLC can only change the setpoints in the controller. To turn off heating, the PLC sends a setpoint of 0 °F.

The PLC monitors the HMI pushbutton used by the operator to turn on or off a nozzle zone.

When the zone is turned on, the PLC changes the MFC controller's setpoint from zero to the airflow setpoint. Once airflow is proven by feedback from the MFC, the PLC will close a relay that allows power to flow to the heater.

At this point, the temperature setpoint is changed from zero to the running setpoint and the Mini8 starts running the heater's Silicon Control Rectifier (SCR).

The temperature deviation and airflow are monitored by the PLC for use in the control logic.

### **Auto Tuning Triggered by the PLC**

The Mini8's program is set up to monitor Digital Input 1 of the Mini8. When energized by the PLC, the Mini8 sets the AutoTune bit on for all four zones.

When auto tuning, start with a cold zone. Turn on the heater to the desired tuning setpoint. Turn on the Auto Tune Start button from the Settings submenu to perform the auto tune.

### **Heater / Airflow Multistate Indicator**

The state of the heating system is reflected by the readout on a multistate indicator. The indicator is bit-triggered, where the lowest numbered bit is used to select the label.

**Table 29. Heater Multistate Indicator and Description**

Bit	Heater Multistate Indicator Label	Comment
0	Controls Not Reset	Power required for heating
1	Heater T/C Broken!	Broken thermocouple sensed by the input module
2	Airflow Not Ready	Airflow reading must be within 2% of the setpoint
3	Heater Turned Off	Heater is not requested to be on
4	Overtemp Control Trip!	O/T control has detected high temperature
5	Part Loaded w/o Heater ON	A mandrel is gripped, but the heater is not turned on by the operator.
6	Tripped on No Temp Increase!	Temperature rise check not passed in time
7	Heater High Temp Deviation!	More than 5 °F above setpoint after reaching setpoint
8	Heater Low Temp Deviation!	More than 5 °F below setpoint after reaching setpoint
9	Heater Not Near Setpoint	Heater must stay with 2 °F of setpoint for 2.5 seconds to be “near setpoint”
10	Airflow Running to Cool Down	Heater is turned off, but the temperature is still above the cool off temperature setting
11	Heater at Temp Limit!	not used
12	Heater is OFF	not used
13	HS13	not used
14	HS14	not used
15	Heater Temperature OK	Always on, all other bits are off.

### Thermocouple Offset

The offset from Settings s21 to s24 are sent from the PLC to the Eurotherm Mini8 controller. The offset is added to the Mini8's thermocouple reading.



## Equipment User Manual

---

---

### CUSTOMER SUPPORT AND SATISFACTION

---

Machine Solutions Inc. is proud of the advanced engineering and quality construction of each piece of equipment that we build. It is our goal to provide equipment that exceeds the expectations of the customer. By implementing the highest standards and applying our experience to provide a quality product, we maintain an ongoing, positive working relationship with all our customers.

Machine Solutions Inc. welcomes your comments and inquiries about our products and services.

Machine Solutions Inc.  
2951 West Shamrell Blvd., Suite 107  
Flagstaff, AZ 86005

Phone: 928-556-3109  
Fax: 928-556-3084  
E-Mail: [service@MachineSolutions.com](mailto:service@MachineSolutions.com)



## Equipment User Manual

---

# WARRANTY AND LIMITATIONS

---

## *General Warranty*

Machine Solutions Inc. (MSI) warrants its products to be free from defects in material and workmanship in normal everyday use and service for a period of one year from the date of shipment from the factory in Flagstaff, Arizona. MSI's obligation under this warranty shall be limited to the repairing or replacing of the product or parts thereof which upon MSI's inspection reveals them to be defective. MSI reserves the right and option to refund the purchase price in lieu of repair or replacement upon evaluation of the returned original part. Modifications, misuse, attempted repairs by others, improper calibration or operation shall render this guarantee null and void. MSI MAKES NO OTHER WARRANTY REGARDING THIS PRODUCT, INCLUDING ANY EXPRESS OR IMPLIED WARRANTY. SPECIFICALLY, THERE IS NO WARRANTY OF MERCHANTABILITY OF THIS PRODUCT OR OF THE FITNESS OF THE PRODUCT FOR ANY PURPOSES. THE SUITABILITY OF THIS PRODUCT FOR ANY PURPOSE PARTICULAR TO THE CUSTOMER IS FOR THE CUSTOMER, IN ITS SOLE JUDGEMENT, TO DETERMINE. MACHINE SOLUTIONS, INC. ASSUMES NO RESPONSIBILITY FOR THE SELECTION OR USE OF THIS PRODUCT BY CUSTOMER. This product has not been tested or approved by the U.S. Food and Drug Administration or any other agency of the U.S. government. This product is not a consumer product as that term is defined in the Magnuson-Moss Warranty – Federal Trade Commission Improvement Act, 15 U.S.C. § 2301 et seq.

---

## *Software License*

By using this equipment, and/or installing or using any of the software associated with the same, you indicate your acceptance of each of the terms of this license. Upon acceptance, this license will be a legally binding agreement between you and MSI. The terms of this license apply to you and to any subsequent user of the software. If you do not agree to all of the terms of this license (i) do not install or use the software and (ii) return the equipment and the software (collectively, equipment), including all components, documentation and any other materials provided with the equipment, to MSI. The software includes associated media, any printed materials, and any on-line or electronic documentation. Software provided by third parties may be subject to separate end-user license agreements from the manufacturers of such software. This license shall also apply to any updates, bug fixes, or newer versions of the software provided by MSI for use with this equipment.

You may: (1) Use the software only in connection with the operation of the equipment; (2) Transfer the software (including all component parts and printed materials) permanently to another person, but only if the person agrees to accept all of the terms of this license. If you transfer the software, you must at the same time transfer the equipment and all copies of the software (if applicable) to the same person or destroy any copies not transferred; and (3) Terminate this license by destroying the original and all copies of the software (if applicable) in whatever form.





## Equipment User Manual

---

You may not: (1) Loan, distribute, rent, lease, give, sublicense or otherwise transfer the software, in whole or in part, to any other person, except as permitted under the transfer paragraph above; (2) Copy or translate the User Guide included with the equipment; (3) Copy, alter, translate, decompile, disassemble or reverse engineer the software, including but not limited to, modifying the software to make it operate on non-compatible hardware; or (4) Remove, alter or cause not to be displayed, any copyright notices or startup message contained in the software programs or documentation

Title to the software, including the ownership of all copyrights, patents, trademarks and all other intellectual property rights subsisting in the foregoing, and all adaptations to and modifications of the foregoing shall at all times remain with MSI and its third party licensors, if any. MSI retains all rights not expressly licensed under this license. Except as otherwise expressly provided in this license, the copying, reproduction, distribution or preparation of derivative works of the software, or any portion of the equipment, is strictly prohibited. Nothing in this license constitutes a waiver by MSI of its rights under United States copyright law.

---

### ***Protection of Intellectual Property***

The equipment and its incorporated technology (collectively referred to herein as the Technology), is protected under issued and pending patents. The Technology is the valuable and proprietary technology, including trade secret technology, belonging to MSI. Much of the Technology is nonpublic and confidential. As our customer, you agree to further assist MSI in the protection of our intellectual property as follows: You agree to keep the Technology you receive confidential at all times, and shall not, without the prior written consent of MSI, disclose the Technology, in whole or in part, to any person outside of your company. You further agree that you shall not reverse engineer, disassemble, decompile or copy the Technology without the prior written consent of MSI.

In addition, you agree that the equipment will not be used to manufacture anything other than products in which you hold intellectual property rights free of infringement of others. You may not use the equipment to manufacture any product infringing on another's patented rights. By accepting and using the equipment, you agree to defend and indemnify Machine Solutions, Inc., its officers, directors, employees and agents, from and against any claims of infringement as a result of your use of the equipment.

---

### ***Regulatory Matters***

All equipment validations, product validation, final product QC testing and other testing required by the U.S Food and Drug Administration are the sole responsibility of the customer. Machine Solutions, Inc. shall have no responsibility or liability for the performance of any interventional product on which this equipment is used.